

How do I use the TV out function?

To enable the tv-out function you need to follow these steps.

- 1) Check if the IC-7000 is connected properly and make sure the TV is set to the AV channel.
- 2) Hold the reset button of the IC-7000
- 3) Power on the IC-7000 and keep holding the reset button for 3 seconds. After 3 seconds release the button.
- 4) Press the reset button again.

