

## Page 1 for : WCDMA / UMTS / HSDPA

1	Huawei E156B/ E156G / E160E / E160G / E169G / E170 / E176 / E180/ E180G / E1550 / E1552 / E1692/ <b>E122</b>
2	Huawei E219 / E220 / E226 / E270 / E272/ E618 / E620 / E626/ E630 / E800 / E1750 / E1820 / <b>K4505</b>
3	Willcom WS002IN / <b>HX004IN</b>
4	SONY MD300 / MD 400
5	BandLuxe C100S / C120 / C170 / C270 / MBD-100HU
6	<b>Softbank C01LC / C02LC</b>
7	Quanta MU-Q101
8	O2 ( Novatel Ovation 930D), O2 (E160)
9	D-link DWM-156 / <b>DWM-652 / DWM-162-U5</b>
10	Option ICON 225 / ICON 401 / <b>GI1515</b>
11	MBD-100HU
12	T-mobile 110 / 530
13	Vodafone (Huawei) K3520 / K3565 / K3715/ K3565 / K3565-Z / K3765

14	<b>Sierra 305 / 306 / 307/ 875U / 880U / C885(AT&amp;T) / Compass 885U / Aircard 875 / Aircard 880E / 888 / C889 / MC8790</b>
15	Novatel MC950D / Merlin XU870
16	ZTE MF100 / MF622 / MF626 / MF627 / MF628 /MF632/ MF636 / MF636DB/ MF637 / MF638 / MF668/ <b>MF110</b>
17	Any Data A2502 / ADU-310A / 520C / Z020 / <b>ADU-635WA</b>
18	LG L-02A / L-05A / <b>HDM-2100</b>
19	4G XS Stick W12 / 4G XS Stick W14
20	Nokia CS-10/CS-15
21	Mywave 2011-T/ FW2011R
Others	KPT WM61, <b>Touchcom TW600U</b> , Maxon BP3 /BP3-Ext , Emobilre D12LC , Shenzhen Crius 209 , Qisda H21(Flying Beetle) Ando MH505UP , FW2011-R-H3G , Alcatel X200 , Prolink PHS 200 , Dhiraagu Touch Maldives , Onda MT503HSA , <b>Lightwave LW HSUPA</b> Micromax MMX 300G , <b>Promate EG05</b> AMOI H01, ASUS T500

## Page 2 for : CDMA / CDMA-2000 / TD-CDMA

	Model Name
1	Sierra Wireless Compass 597 / 598 / 598U
2	Alltel (Pantech) UM150AL / UM175AL
3	Huawei EC-169 / EC-228 / EC-1260 / EC-1261 / ET-128
4	C-motech CDU-550 / D-50
5	Kyocera KPC680 Express Card
6	Novatel MC760 (Verizon)/ U727
7	Rilan EV8900U / EV8900UL
8	Touchcom UC126/UC928/UC988/V605U/EU930
9	ZTE AC560/AC580/AC581/AC2726/AC2736 /AC8710
Others	Cooxoo ZX200 / Caoran CC130 / GAORAN CC130 / Gold Space E800 / Vtion E1916 / Axesstel MV140A / Panda PT20 / Sprint 4G / Samsung SCH-U209

## 3G-6200n Print Server Compatible List

	Model Name
Canon	ip100, ip1980, ip3680, ip4680, iP5000, PIXMA IP3500, PIXMA MP198, PIXMA MP198, PIXMA MP268, PIXMA MP486, PIXMA MP520, PIXMA MP545, PIXMA MP638
EPSON	Aculaser C1100, Aculaser C3800N, EC-01, LQ-300+ II, Stylus C59, STYLUS CX3700, Stylus CX4100, STYLUS CX4900, STYLUS CX5505, STYLUS CX6900F, STYLUS CX7300, STYLUS CX8300, STYLUS CX9300F, Stylus Photo 1390, Stylus Photo 750, STYLUS PHOTO EX3, Stylus Photo R1900, STYLUS PHOTO R290, STYLUS PHOTO RX690, Stylus TX200
HP	Color Laserjet 2550L, Color Laserjet 2605, Color Laserjet CM1015, Color Laserjet CM1017, Color Laserjet CP3505dn, Color LaserJet CP3525, Deskjet 3650, Deskjet 3940, Deskjet 930cxi, Deskjet F2120, LaserJet 3020, LaserJet 3030, LaserJet 3055, LaserJet P2014, LaserJet P2015, OfficeJet 4255, Officejet 5610, Officejet Pro K5300, Photosmart 8230, Photosmart C4480, Photosmart C4580, Photosmart C5380, Photosmart D5460, Photosmart D7360, PSC 1210, PSC 1510, PSC 1610, PSC 2110, PSC 2210, PSC 2310, PSC 2355, PSC 2410, PSC 2510
Konica Minolta	bizhub210
Kyocera	FS-1030D, FS-1100, FS-920
LEXMARK	Z1420, Z603, Z645
SAMSUNG	CLX-2160N, ML-1610, ML-2010, SCX-4720F